



SG ARCHERW8 – DMX Chart

rev_01-0723

DMX table compact version

TW (15CH)	Basic (16CH)	Standard (25CH)	Extend (99CH)	Circles (38CH)	Sectors (58CH)	CMY (24CH)	Function
1	1	1	1	1	1	1	Pan
2		2	2	2	2	2	Pan fine
3	2	3	3	3	3	3	Tilt
4		4	4	4	4	4	Tilt fine
5	3	5	5	5	5	5	Pan/Tilt speed
6	4	6	6	6	6	6	Dimmer
7			7	7	7	7	Dimmer fine
8	5	7	8	8	8	8	Strobe
9	6	8	9	9	9	9	Zoom
10			10	10	10	10	Zoom fine
		9	11	11	11	11	Zoom speed
	7	10	12				Red - Red 1 (in 99CH mode)
	8	11	13				Green - Green 1 (in 99CH mode)
	9	12	14				Blue - Blue 1 (in 99CH mode)
	10	13	15				White - White 1 (in 99CH mode)
			16				Red 2
			17				Green 2
			18				Blue 2
			19				White 2
			20				Red 3
			21				Green 3
			22				Blue 3
			23				White 3
			24				Red 4
			25				Green 4
			26				Blue 4
			27				White 4
			28				Red 5
			29				Green 5
			30				Blue 5
			31				White 5
			32				Red 6
			33				Green 6
			34				Blue 6
			35				White 6
			36				Red 7
			37				Green 7
			38				Blue 7
			39				White 7
			40				Red 8
			41				Green 8
			42				Blue 8
			43				White 8



SG ARCHERW8 – DMX Chart

rev_01-0723

			44			Red 9
			45			Green 9
			46			Blue 9
			47			White 9
			48			Red 10
			49			Green 10
			50			Blue 10
			51			White 10
			52			Red 11
			53			Green 11
			54			Blue 11
			55			White 11
			56			Red 12
			57			Green 12
			58			Blue 12
			59			White 12
			60			Red 13
			61			Green 13
			62			Blue 13
			63			White 13
			64			Red 14
			65			Green 14
			66			Blue 14
			67			White 14
			68			Red 15
			69			Green 15
			70			Blue 15
			71			White 15
			72			Red 16
			73			Green 16
			74			Blue 16
			75			White 16
			76			Red 17
			77			Green 17
			78			Blue 17
			79			White 17
			80			Red 18
			81			Green 18
			82			Blue 18
			83			White 18
			84			Red 19
			85			Green 19
			86			Blue 19
			87			White 19
			12			Master dimmer C1
			13			Red C1



SG ARCHERW8 – DMX Chart

rev_01-0723

				14		Green C1
				15		Blue C1
				16		White C1
				17		Master dimmer C2
				18		Red C2
				19		Green C2
				20		Blue C2
				21		White C2
				22		Master dimmer C3
				23		Red C3
				24		Green C3
				25		Blue C3
				26		White C3
				12		Master dimmer Center
				13		Red Center
				14		Green Center
				15		Blue Center
				16		White Center
				17		Master dimmer S1
				18		Red S1
				19		Green S1
				20		Blue S1
				21		White S1
				22		Master dimmer S2
				23		Red S2
				24		Green S2
				25		Blue S2
				26		White S2
				27		Master dimmer S3
				28		Red S3
				29		Green S3
				30		Blue S3
				31		White S3
				32		Master dimmer S4
				33		Red S4
				34		Green S4
				35		Blue S4
				36		White S4
				37		Master dimmer S5
				38		Red S5
				39		Green S5
				40		Blue S5
				41		White S5
				42		Master dimmer S6
				43		Red S6
				44		Green S6

					45		Blue S6
					46		White S6
						12	Cyan
						13	Cyan fine
						14	Magenta
						15	Magenta fine
						16	Yellow
						17	Yellow fine
		14	88	27	47	18	White Macros
11		15	89	28	48	19	Linear White
12		16	90	29	49		Minus green (this function works only in combination with White Macros or Linear White functions)
	11	17	91	30	50	20	Foreground colors
	12	18	92	31	51		Background colors (this function works only in combination with pattern programs)
		19	93	32	52	21	Fade speed foreground and background colors
	13	20	94	33	53		Pattern programs
	14	21	95	34	54		Patterns movement
	15	22	96	35	55		Pattern Fade
13		23	97	36	56	22	Dimmer modes
14		24	98	37	57	23	Dimmer curves
15	16	25	99	38	58	24	Special functions

DMX table extended version

TW (15CH)	Basic (16CH)	Standard (25CH)	Extend (99CH)	Circles (38CH)	Sectors (58CH)	CMY (24CH)	Function	Value	Detail	
1	1	1	1	1	1	1	Pan	000 - 255	Pan movement	
2		2	2	2	2	2	Pan fine	000 - 255	Pan fine movement	
3	2	3	3	3	3	3	Tilt	000 - 255	Tilt movement	
4		4	4	4	4	4	Tilt fine	000 - 255	Tilt fine movement	
5	3	5	5	5	5	5	Pan/Tilt speed	000 - 225	Speed from Max to min	
								226 - 235	Blackout by movements	
								236 - 255	No functions	
6	4	6	6	6	6	6	Dimmer	000 - 255	Master dimmer	
7			7	7	7	7	7	Dimmer fine	000 - 255	Master dimmer fine
8	5	7	8	8	8	8	Strobe	000 - 031	Shutter closed	
								032 - 063	Shutter open	
								064 - 095	Strobe from slow to fast	
								096 - 127	Shutter open	
								128 - 157	Pulse IN ALL PIXELS from slow to fast	
								158 - 159	Shutter open	
								160 - 189	Random Pulse IN SINGLE PIXEL from slow to fast	
								190 - 191	Shutter open	
								192 - 221	Random strobe ALL PIXELS from slow to fast	
								222 - 223	Shutter open	
224 - 253	Random strobe SINGLE PIXEL from slow to fast									



SG ARCHERW8 – DMX Chart

rev_01-0723

								254 - 255	Shutter open
9	6	8	9	9	9	9	Zoom	000 - 255	Zoom from narrow to wide
10			10	10	10	10	Zoom fine	000 - 255	Zoom from narrow to wide fine
		9	11	11	11	11	Zoom speed	000 - 255	Zoom speed from max to min
	7	10	12				Red - Red 1	000 - 255	Red dimmer (Red 1 in 99CH mode)
	8	11	13				Green - Green 1	000 - 255	Green dimmer (Green 1 in 99CH mode)
	9	12	14				Blue - Blue 1	000 - 255	Blue dimmer (Blue 1 in 99CH mode)
	10	13	15				White - White 1	000 - 255	White dimmer (White 1 in 99CH mode)
			16				Red 2	000 - 255	Red 2 dimmer
			17				Green 2	000 - 255	Green 2 dimmer
			18				Blue 2	000 - 255	Blue 2 dimmer
			19				White 2	000 - 255	White 2 dimmer
			20				Red 3	000 - 255	Red 3 dimmer
			21				Green 3	000 - 255	Green 3 dimmer
			22				Blue 3	000 - 255	Blue 3 dimmer
			23				White 3	000 - 255	White 3 dimmer
			24				Red 4	000 - 255	Red 4 dimmer
			25				Green 4	000 - 255	Green 4 dimmer
			26				Blue 4	000 - 255	Blue 4 dimmer
			27				White 4	000 - 255	White 4 dimmer
			28				Red 5	000 - 255	Red 5 dimmer
			29				Green 5	000 - 255	Green 5 dimmer
			30				Blue 5	000 - 255	Blue 5 dimmer
			31				White 5	000 - 255	White 5 dimmer
			32				Red 6	000 - 255	Red 6 dimmer
			33				Green 6	000 - 255	Green 6 dimmer
			34				Blue 6	000 - 255	Blue 6 dimmer
			35				White 6	000 - 255	White 6 dimmer
			36				Red 7	000 - 255	Red 7 dimmer
			37				Green 7	000 - 255	Green 7 dimmer
			38				Blue 7	000 - 255	Blue 7 dimmer
			39				White 7	000 - 255	White 7 dimmer
			40				Red 8	000 - 255	Red 8 dimmer
			41				Green 8	000 - 255	Green 8 dimmer
			42				Blue 8	000 - 255	Blue 8 dimmer
			43				White 8	000 - 255	White 8 dimmer
			44				Red 9	000 - 255	Red 9 dimmer
			45				Green 9	000 - 255	Green 9 dimmer
			46				Blue 9	000 - 255	Blue 9 dimmer
			47				White 9	000 - 255	White 9 dimmer
			48				Red 10	000 - 255	Red 10 dimmer
			49				Green 10	000 - 255	Green 10 dimmer
			50				Blue 10	000 - 255	Blue 10 dimmer
			51				White 10	000 - 255	White 10 dimmer
			52				Red 11	000 - 255	Red 11 dimmer
			53				Green 11	000 - 255	Green 11 dimmer



SG ARCHERW8 – DMX Chart

rev_01-0723

			54			Blue 11	000 - 255	Blue 11 dimmer
			55			White 11	000 - 255	White 11 dimmer
			56			Red 12	000 - 255	Red 12 dimmer
			57			Green 12	000 - 255	Green 12 dimmer
			58			Blue 12	000 - 255	Blue 12 dimmer
			59			White 12	000 - 255	White 12 dimmer
			60			Red 13	000 - 255	Red 13 dimmer
			61			Green 13	000 - 255	Green 13 dimmer
			62			Blue 13	000 - 255	Blue 13 dimmer
			63			White 13	000 - 255	White 13 dimmer
			64			Red 14	000 - 255	Red 14 dimmer
			65			Green 14	000 - 255	Green 14 dimmer
			66			Blue 14	000 - 255	Blue 14 dimmer
			67			White 14	000 - 255	White 14 dimmer
			68			Red 15	000 - 255	Red 15 dimmer
			69			Green 15	000 - 255	Green 15 dimmer
			70			Blue 15	000 - 255	Blue 15 dimmer
			71			White 15	000 - 255	White 15 dimmer
			72			Red 16	000 - 255	Red 16 dimmer
			73			Green 16	000 - 255	Green 16 dimmer
			74			Blue 16	000 - 255	Blue 16 dimmer
			75			White 16	000 - 255	White 16 dimmer
			76			Red 17	000 - 255	Red 17 dimmer
			77			Green 17	000 - 255	Green 17 dimmer
			78			Blue 17	000 - 255	Blue 17 dimmer
			79			White 17	000 - 255	White 17 dimmer
			80			Red 18	000 - 255	Red 18 dimmer
			81			Green 18	000 - 255	Green 18 dimmer
			82			Blue 18	000 - 255	Blue 18 dimmer
			83			White 18	000 - 255	White 18 dimmer
			84			Red 19	000 - 255	Red 19 dimmer
			85			Green 19	000 - 255	Green 19 dimmer
			86			Blue 19	000 - 255	Blue 19 dimmer
			87			White 19	000 - 255	White 19 dimmer
			12			Dimmer C1	000 - 255	Master dimmer C1
			13			Red C1	000 - 255	Red Circle 1 dimmer
			14			Green C1	000 - 255	Green Circle 1 dimmer
			15			Blue C1	000 - 255	Blue Circle 1 dimmer
			16			White C1	000 - 255	White Circle 1 dimmer
			17			Dimmer C2	000 - 255	Master dimmer C2
			18			Red C2	000 - 255	Red Circle 2 dimmer
			19			Green C2	000 - 255	Green Circle 2 dimmer
			20			Blue C2	000 - 255	Blue Circle 2 dimmer
			21			White C2	000 - 255	White Circle 2 dimmer
			22			Dimmer C3	000 - 255	Master dimmer C3
			23			Red C3	000 - 255	Red Circle 3 dimmer



SG ARCHERW8 – DMX Chart

rev_01-0723

				24			Green C3	000 - 255	Green Circle 3 dimmer
				25			Blue C3	000 - 255	Blue Circle 3 dimmer
				26			White C3	000 - 255	White Circle 3 dimmer
					12		Dimmer Center	000 - 255	Master dimmer Center
					13		Red Center	000 - 255	Red Center dimmer
					14		Green Center	000 - 255	Green Center dimmer
					15		Blue Center	000 - 255	Blue Center dimmer
					16		White Center	000 - 255	White Center dimmer
					17		Dimmer S1	000 - 255	Master dimmer S1
					18		Red S1	000 - 255	Red Sector 1 dimmer
					19		Green S1	000 - 255	Green Sector 1 dimmer
					20		Blue S1	000 - 255	Blue Sector 1 dimmer
					21		White S1	000 - 255	White Sector 1 dimmer
					22		Dimmer S2	000 - 255	Master dimmer S2
					23		Red S2	000 - 255	Red Sector 2 dimmer
					24		Green S2	000 - 255	Green Sector 2 dimmer
					25		Blue S2	000 - 255	Blue Sector 2 dimmer
					26		White S2	000 - 255	White Sector 2 dimmer
					27		Dimmer S3	000 - 255	Master dimmer S3
					28		Red S3	000 - 255	Red Sector 3 dimmer
					29		Green S3	000 - 255	Green Sector 3 dimmer
					30		Blue S3	000 - 255	Blue Sector 3 dimmer
					31		White S3	000 - 255	White Sector 3 dimmer
					32		Dimmer S4	000 - 255	Master dimmer S4
					33		Red S4	000 - 255	Red Sector 4 dimmer
					34		Green S4	000 - 255	Green Sector 4 dimmer
					35		Blue S4	000 - 255	Blue Sector 4 dimmer
					36		White S4	000 - 255	White Sector 4 dimmer
					37		Dimmer S5	000 - 255	Master dimmer S5
					38		Red S5	000 - 255	Red Sector 5 dimmer
					39		Green S5	000 - 255	Green Sector 5 dimmer
					40		Blue S5	000 - 255	Blue Sector 5 dimmer
					41		White S5	000 - 255	White Sector 5 dimmer
					42		Dimmer s6	000 - 255	Master dimmer S6
					43		Red S6	000 - 255	Red Sector 6 dimmer
					44		Green S6	000 - 255	Green Sector 6 dimmer
					45		Blue S6	000 - 255	Blue Sector 6 dimmer
					46		White S6	000 - 255	White Sector 6 dimmer
						12	Cyan	000 - 255	Cyan dimmer (active only in CMY - 24CH mode)
						13	Cyan fine	000 - 255	Cyan dimmer fine (active only in CMY - 24CH mode)
						14	Magenta	000 - 255	Magenta dimmer (active only in CMY - 24CH mode)
						15	Magenta fine	000 - 255	Magenta dimmer fine (active only in CMY - 24CH mode)
						16	Yellow	000 - 255	Yellow dimmer (active only in CMY - 24CH mode)
						17	Yellow fine	000 - 255	Yellow dimmer fine (active only in CMY - 24CH mode)
		14	88	27	47	18	White Macros	0	No functions
								001 - 025	2700K

								026 - 050	3000K
								051 - 075	3200K
								076 - 100	4000K
								101 - 125	4500K
								126 - 150	5000K
								151 - 175	5600K
								176 - 200	6500K
								201 - 225	8000K
								226 - 255	10000K
11		15	89	28	48	19	Linear White	0	No functions
								001 - 255	Linear Color Temperature from 2700K to 10000K
12		16	90	29	49		Minus green (this function works only in combination with White Macros or Linear White functions)	000	No Function
								001 - 255	Minus green from no green removed to Max green removed
								0	No functions
								001 - 004	Pale Yellow (LEE filter number 7)
								005 - 008	Straw (LEE filter number 103)
								009 - 012	Gold Tint (LEE filter number 151)
								013 - 016	Spring Yellow (LEE filter number 100)
								017 - 020	Medium Yellow (LEE filter number 10)
								021 - 024	Yellow (LEE filter number 101)
								025 - 028	Deep Amber (LEE filter number 104)
								029 - 032	Deep Straw (LEE filter number 15)
								033 - 036	Loving Amber (LEE filter number 179)
								037 - 040	Gold Amber (LEE filter number 21)
								041 - 044	Orange (LEE filter number 105)
								045 - 048	Deep Orange (LEE filter number 158)
								049 - 052	Dark Amber (LEE filter number 22)
								053 - 056	Millenium Gold (LEE filter number 778)
	11	17	91	30	50	20	Foreground colors	057 - 060	Deep Golden Amber (LEE filter number 135)
								061 - 064	Scarlet (LEE filter number 24)
								065 - 068	Primary Red (LEE filter number 106)
								069 - 072	Bright Red (LEE filter number 26)
								073 - 076	Medium Red (LEE filter number 27)
								077 - 080	Fire (LEE filter number 19)
								081 - 084	Pink (LEE filter number 157)
								085 - 088	Medium Pink (LEE filter number 36)
								089 - 092	Dark Pink (LEE filter number 111)
								093 - 096	Bright Pink (LEE filter number 128)
								097 - 100	Bright Rose (LEE filter number 148)
								101 - 104	Special Rose Pink (LEE filter number 332)
								105 - 108	Vanity Fair (LEE filter number 793)
								109 - 112	Magenta (LEE filter number 113)
								113 - 116	Dark Magenta (LEE filter number 46)
								117 - 120	Rose Purple (LEE filter number 48)



SG ARCHERW8 – DMX Chart

rev_01-0723

								121 - 124	Mauve (LEE filter number 126)
								125 - 128	Medium Purple (LEE filter number 49)
								129 - 132	Lavender (LEE filter number 58)
								133 - 136	Palace Blue (LEE filter number 199)
								137 - 140	Dark Blue (LEE filter number 119)
								141 - 144	Medium Blue (LEE filter number 132)
								145 - 148	Deep Blue (LEE filter number 120)
								149 - 152	Daylight Blue (LEE filter number 165)
								153 - 156	Slate Blue (LEE filter number 161)
								157 - 160	Light Blue (LEE filter number 118)
								161 - 164	Sky Blue (LEE filter number 68)
								165 - 168	Pale Navy Blue (LEE filter number 143)
								169 - 172	Marine Blue (LEE filter number 131)
								173 - 176	Peacock Blue (LEE filter number 115)
								177 - 180	Lagoon Blue (LEE filter number 172)
								181 - 184	Medium Blue Green (LEE filter number 116)
								185 - 188	Dark Yellow Green (LEE filter number 90)
								189 - 192	Primary Green (LEE filter number 139)
								193 - 196	Fern Green (LEE filter number 122)
								197 - 200	Moss Green (LEE filter number 89)
								201 - 204	Dark Green (LEE filter number 124)
								205 - 208	Lime Green (LEE filter number 88)
								209 - 212	Pale Green (LEE filter number 138)
								213 - 216	Quarter CT Blue (LEE filter number 203)
								217 - 220	Half CT Blue (LEE filter number 202)
								221 - 224	Full CT Blue (LEE filter number 201)
								225 - 228	Double CT Blue (LEE filter number 200)
								229 - 232	Quarter CT Orange (LEE filter number 206)
								233 - 236	Half CT Orange (LEE filter number 205)
								237 - 240	Full CT Orange (LEE filter number 204)
								241 - 250	Rainbow color from slow to fast (from the first to the last color)
								251 - 255	Full ON
								0	No functions
								001 - 004	Pale Yellow (LEE filter number 7)
								005 - 008	Straw (LEE filter number 103)
								009 - 012	Gold Tint (LEE filter number 151)
								013 - 016	Spring Yellow (LEE filter number 100)
								017 - 020	Medium Yellow (LEE filter number 10)
								021 - 024	Yellow (LEE filter number 101)
								025 - 028	Deep Amber (LEE filter number 104)
								029 - 032	Deep Straw (LEE filter number 15)
								033 - 036	Loving Amber (LEE filter number 179)
								037 - 040	Gold Amber (LEE filter number 21)
								041 - 044	Orange (LEE filter number 105)
								045 - 048	Deep Orange (LEE filter number 158)
								049 - 052	Dark Amber (LEE filter number 22)
	12	18	92	31	51		Background colors (this function works only in combination with pattern programs)		



SG ARCHERW8 – DMX Chart

rev_01-0723

										053 - 056	Millenium Gold (LEE filter number 778)
										057 - 060	Deep Golden Amber (LEE filter number 135)
										061 - 064	Scarlet (LEE filter number 24)
										065 - 068	Primary Red (LEE filter number 106)
										069 - 072	Bright Red (LEE filter number 26)
										073 - 076	Medium Red (LEE filter number 27)
										077 - 080	Fire (LEE filter number 19)
										081 - 084	Pink (LEE filter number 157)
										085 - 088	Medium Pink (LEE filter number 36)
										089 - 092	Dark Pink (LEE filter number 111)
										093 - 096	Bright Pink (LEE filter number 128)
										097 - 100	Bright Rose (LEE filter number 148)
										101 - 104	Special Rose Pink (LEE filter number 332)
										105 - 108	Vanity Fair (LEE filter number 793)
										109 - 112	Magenta (LEE filter number 113)
										113 - 116	Dark Magenta (LEE filter number 46)
										117 - 120	Rose Purple (LEE filter number 48)
										121 - 124	Mauve (LEE filter number 126)
										125 - 128	Medium Purple (LEE filter number 49)
										129 - 132	Lavender (LEE filter number 58)
										133 - 136	Palace Blue (LEE filter number 199)
										137 - 140	Dark Blue (LEE filter number 119)
										141 - 144	Medium Blue (LEE filter number 132)
										145 - 148	Deep Blue (LEE filter number 120)
										149 - 152	Daylight Blue (LEE filter number 165)
										153 - 156	Slate Blue (LEE filter number 161)
										157 - 160	Light Blue (LEE filter number 118)
										161 - 164	Sky Blue (LEE filter number 68)
										165 - 168	Pale Navy Blue (LEE filter number 143)
										169 - 172	Marine Blue (LEE filter number 131)
										173 - 176	Peacock Blue (LEE filter number 115)
										177 - 180	Lagoon Blue (LEE filter number 172)
										181 - 184	Medium Blue Green (LEE filter number 116)
										185 - 188	Dark Yellow Green (LEE filter number 90)
										189 - 192	Primary Green (LEE filter number 139)
										193 - 196	Fern Green (LEE filter number 122)
										197 - 200	Moss Green (LEE filter number 89)
										201 - 204	Dark Green (LEE filter number 124)
										205 - 208	Lime Green (LEE filter number 88)
										209 - 212	Pale Green (LEE filter number 138)
										213 - 216	Quarter CT Blue (LEE filter number 203)
										217 - 220	Half CT Blue (LEE filter number 202)
										221 - 224	Full CT Blue (LEE filter number 201)
										225 - 228	Double CT Blue (LEE filter number 200)
										229 - 232	Quarter CT Orange (LEE filter number 206)
										233 - 236	Half CT Orange (LEE filter number 205)

								237 - 240	Full CT Orange (LEE filter number 204)
								241 - 250	Rainbow color from slow to fast (from the first to the last color)
								251 - 255	Full ON
		19	93	32	52	21	Fade speed foreground and background colors	000 - 255	Fade from 0 to max fade
	13	20	94	33	53		Pattern programs	000 - 009	No functions
								010 - 019	Pattern program 1
								020 - 029	Pattern program 2
								030 - 039	Pattern program 3
								040 - 049	Pattern program 4
								050 - 059	Pattern program 5
								060 - 069	Pattern program 6
								070 - 079	Pattern program 7
								080 - 089	Pattern program 8
								090 - 099	Pattern program 9
								100 - 109	Pattern program 10
								110 - 119	Pattern program 11
								120 - 129	Pattern program 12
								130 - 139	Pattern program 13
								140 - 149	Pattern program 14
								150 - 159	Pattern program 15
								160 - 169	Pattern program 16
								170 - 179	Pattern program 17
								180 - 189	Pattern program 18
								190 - 199	Pattern program 19
								200 - 209	Pattern program 20
								210 - 255	No functions
	14	21	95	34	54		Pattern programs manual step	000 - 004	Static Step 1
								005 - 009	Static Step 2
								010 - 014	Static Step 3
								015 - 019	Static Step 4
								020 - 024	Static Step 5
								025 - 029	Static Step 6
								030 - 034	Static Step 7
								035 - 039	Static Step 8
							Pattern programs auto step	040 - 145	Chase forward from fast to slow
								146 - 149	Stop
								150 - 255	Chase forward from slow to fast
	15	22	96	35	55		Pattern Fade	000 - 255	Pattern fade from 0 to max fade
13		23	97	36	56	22	Dimmer modes	000 - 020	Standard
								021 - 040	Stage
								041 - 060	TV
								061 - 080	Architectural
								081 - 100	Theatre
								101 - 255	No functions: settings from display

14	24	98	37	57	23	Dimmer curves	000 - 020	Linear	
							021 - 040	Square	
							041 - 060	Inv-square	
							061 - 080	S-curve	
							081 - 255	No functions: settings from display	
15	16	25	99	38	58	24	Special functions (Hold 3s to activate)	000 - 005	No functions
								006 - 010	900 Hz LED refresh rate
								011 - 015	1000 Hz LED refresh rate
								016 - 020	1100 Hz LED refresh rate
								021 - 025	1200 Hz LED refresh rate
								026 - 030	1300 Hz LED refresh rate
								031 - 035	1400 Hz LED refresh rate
								036 - 040	1500 Hz LED refresh rate
								041 - 045	2500 Hz LED refresh rate
								046 - 050	4000 Hz LED refresh rate
								051 - 055	5000 Hz LED refresh rate
								056 - 060	6000 Hz LED refresh rate
								061 - 065	10 KHz LED refresh rate
								066 - 070	15 KHz LED refresh rate
								071 - 075	20 KHz LED refresh rate
								076 - 080	25 KHz LED refresh rate
								081 - 089	LED refresh rate settings from display
								090 - 099	Invert Pan ON
								100 - 109	Invert Pan OFF
								110 - 119	Invert Tilt ON
								120 - 129	Invert Tilt OFF
								130 - 139	Fan Silent
								140 - 149	Fan Auto
								150 - 159	Fan High
160 - 169	Pan/Tilt Reset								
170 - 179	Zoom Reset								
180 - 189	Total Reset								
190 - 255	No functions								